

KWIKSET SMART CODE INSTRUCTIONS

How to perform a factory reset:

1. Remove the batteries.
2. Press and hold the program button on the keypad.
3. Place the batteries back in (while still holding the button)
4. The lock will beep three times over the course of 15 seconds or so. After the 3rd beep release the button.

How to hand the unit click on the link below for handing instructions

<https://www.youtube.com/watch?v=oqafKET3Qpl>